

OPERATING MANUAL

Crius C400 with Indirect Lighting - Basic On/Off

Important: Please read the instruction manual carefully prior to installation and keep it for future reference.



Order Code	Product Series	Power	Function Description
C400 32 000-IND	Crius C400	32W	Basic On/Off

60mm Ф 400mm

Mounting: Wall or Ceiling Light features:


Ra: >80

Life Time: 5 years


Light Source: LED SMD2835 Input: 220V-240V 50/60Hz




No.	Pic	Qty.	Usage
1	()	3	Fix light
2	\Rightarrow	3	Rawl plug
3	0	3	Plastic washer
4		2	Cable clip
5	-	4	Fix cable clip




Installation




Twist the diffuser anticlockwise. Vertically remove the diffuser and PCBA.




- a. Cut off the power. Thread the input cable through the rubber plug to the fixture. Connect the wire referring to the wiring diagram.
- b. Knock the rawl plugs into the pre-drilled holes on ceiling /wall. Wear plastic washers on self-tapping screws and tighten them to fix the fixture on ceiling/wall.




Install the cable clip.



Mount the diffuser onto the base by twisting clockwise.




Connect the DC cable.




Installation finished.

Wiring




Maintenance

- 1. Cut off the main power first.
- 2. Don't touch LEDs while maintaining or cleaning.
- 3. Don't use chemicals to clean the fixture.







Environmental protection: waste electrical products should not be disposed of with household waste. Please recycle where facilities exist. Check with your local authority or retailer for recycling advice.

Caution

- 1. The product must be installed by professional technicians and power supply must be cut off before installation.
- The diameter for AC input wire is 0.75mm² (complying with 60245 IEC57), which complies with the latest IEE electrical standards or national standards.
- 3. Do not touch the electronic circuit and its components.
- 4. Contact an authorised technical service centre for any repairs possibly required use only original spare parts.
- 5. Do not touch LED while installing or maintaining.
- 6. Sealing the entrance hole with glue after install is needed.
- 7. The light source contained in this luminaire shall only be replaced by the manufacturer or his service agent or a similar qualified person.

